



NX3 dual-cure cement exhibits unparalleled color stability with its patented *amine-free* initiator system.

INLAY/ONLAY




1. Apply try-in gel to restoration and seat. Check color and fit. Remove restoration.



2. Thoroughly wash out try-in gel. Air dry. Shield silane primer from ambient light and apply.


BONDING




3. Select bonding system and apply to prep.




4. Dispense NX3 cement (light-cure or dual-cure) directly into veneer.



5. Seat veneer. Spot cure for several seconds. Remove mylar strip. Clean excess cement from margins.



6. Light cure all surfaces for 20 seconds each.**




7. Finish and polish.

NX3's optimal handling allows easy cleanup in gel state.

CERAMIC CROWNS




1. Apply try-in gel to restoration and seat. Check color and fit. Remove restoration.




2. Thoroughly wash out try-in gel. Air dry. Shield silane primer from ambient light and apply.


BONDING




3. Select bonding system and apply to prep.




4. Dispense NX3 cement (light-cure or dual-cure) onto restoration or prep.



5. Seat restoration onto prep, allowing cement to flow from all sides. Tack cure (1-2 seconds) to facilitate cleanup. Remove excess cement.



6. Light cure all surfaces for 20 seconds each.**



7. Finish and polish.


Due to its proprietary *amine-free* initiator system, NX3 dual-cure cement exhibits superior compatibility with both total-etch and self-etch adhesives in dark-cure situations where there is limited light accessibility.

NX3 simplifies your procedure – it is not necessary to use a primer/adhesive on the metal surface.


METAL-BASED CROWNS




BONDING




3. Select bonding system and apply to prep.




4. Dispense NX3 dual-cure cement onto restoration or prep.



5. Seat restoration onto prep, allowing cement to flow from all sides. Tack cure (1-2 seconds) to facilitate cleanup. Remove excess cement.




6. Light cure all surfaces for 20 seconds each.**



7. Finish and polish.


NX3 can be used as a core build-up material. Its excellent dark-cure compatibility with acidic adhesives enables bulk filling ability.

POSTS & CORE




1. Prepare post space.
Size and fit post.


BONDING




1. Select bonding system and apply to prep.




2. Sandblast & clean inside surface of restoration.
Dispense NX3 dual-cure cement onto restoration or prep.



3. Seat restoration onto prep, allowing cement to flow from all sides.
Tack cure (1-2 seconds) to facilitate cleanup.



Remove excess cement.
4. Light cure all surfaces for 20 seconds each.**



5. Finish and polish.